



PSyclone's PSyData API – Or: Tools Tools Tools

Rupert Ford, Andy Porter, Sergi Siso, STFC Hartree Centre
Iva Kavcic, Chris Maynard, Andrew Coughtrie, UK Met Office
Joerg Henrichs, Australian Bureau of Meteorology

ESIWACE2 training course on Domain-specific Languages in Weather
and Climate, 23rd-27th November 2020

Overview

- PSyclone transformations (~ 20 minutes)
- What is the PSyData interface? (~ 25 minutes)
 - How to use them
 - Which tools are available and planned
- Hands-on session (~45 minutes)



PSyclone Transformations

- Transformation allow to modify the PSyIR tree
 - Modify existing code
 - Add new code
- Crucial for separation of concerns
 - Transformations can be independent of the code
 - Change code for
 - Optimisation
 - Parallelisation
 - Add debugging feature
- Transformations are Python scripts
 - Using PSyclone objects

Transformation vs Transformation Script

- A **transformation** is a instance of a class that modifies the PSyIR tree and has two methods:
 - validate() – verify that the transform can be applied
 - apply() – apply the transform
 - Calls validate() first
 - Needs to be instantiated
- A **transformation script** has
 - A single functions `trans()` to modify the PSyIR tree
 - Is specified on the command line using -s
 - trans() is called by PSyclone once per file
 - Typically uses one or more transformations



Applying a Transformation Script

- A Python transformation script can be specified on the PSyclone command line:

```
psyclone ... -s ./my_script.py  
\  
          -opsy psy.f90           \  
          -oalg alg.f90 file.x90
```

- The script must contain the `trans()` function, which is called once per file
 - After distributed memory has been added to PSyIR (see presentation later)
 - OpenMP is added using this kind of script (see presentation later)



A Transformation Script

```
def trans(psy):  
    '''
```

Take the supplied psy object, and transform it

```
:param psy: the PSy layer to transform.  
:type psy: :py:class:`psyclone.psyGen.PSy`
```

```
:returns: the transformed PSy object.  
:rtype: :py:class:`psyclone.psyGen.PSy`  
'''
```

- Parameter: the PSyclone top level PSy object, gives access to PSyIR



The PSy Object

- Contains a list of invokes
 - Subroutine call to PSy-layer
- Each invoke:
 - (nested) loop structure (depending on API)
 - Kernel computation
 - Kernel can have various complexities
 - LFRic: loop over column
 - Other APIs: call to a single element, or 'computations'



Getting the Invokes

- By name for a single invoke:

```
psy.invokes.get("invoke_name")  
    # 'name' is specified in invoke
```

- By index:

```
psy.invokes.invoke_list[n]
```

- Loop over names:

```
for name in psy.invokes.names:  
    invoke = psy.invokes.get(name)
```



Schedules

- A schedule stores a sequence of statements
- Each invoke has one schedule:
`schedule = invoke.schedule`
- Example:

```
InvokeSchedule[invoke='invoke_propagate_perturbation', dm=False]
0: Loop[type='', field_space='w3', ...]
    Literal [...]
    Schedule[]
        0: CodedKern prop_perturb(
            perturbation, chi, t_tot)
```

Using a Transformation

- Import it:

```
from psyclone.psyir.transformations \
import SomeTrans
```

Transformation are currently being refactored

- Create an instance:

```
some_trans = SomeTrans()
```

- Apply the transformation to a single node, list of nodes, or schedule:

```
some_trans.apply(some_psyir_nodes)
```



Need for Transformation Options

- Some transformations need additional parameters:
 - Loop collapse: How many nested loop to collapse
 - OMP reductions: if reproductions should be reproducible (i.e. independent of # processes....)
 - OMP parallel: whether to check for allowed node types (e.g. a write-statement would not be allowed)

...

Parameters for Transformations

- Both `validate()` and `apply()` take one optional parameter called 'options'
- This is a Python dictionary that specifies additional, transformation-specific parameters:

```
options = {"node-type-check": False}  
some_trans.apply(some_psyir_nodes,  
                  options)
```
- Note: at this stage an invalid key in the option dictionary is not flagged as an error

```
some_trans.apply(nodes,  
                 {'node-type-check': False})
```

Putting it Together

```
def trans(psy):
    from psyclone.psyir.transformations \
        import ExtractTrans
    extract = ExtractTrans()

    invoke    = psy.invokes.get("invoke_name")
    schedule = invoke.schedule
    schedule.view()
    # Enclose everything in an extract region
    options  = {}
    extract.apply(schedule, options)

    schedule.view()
    return psy
```



Outcome: One Node Inserted

```
InvokeSchedule[invoke='invoke_propagate_perturbation',  
dm=False]
```

```
0: Loop[type='', field_space='w3', it_space=...]
```

```
    Schedule[]
```

```
        0: CodedKern prop_pert_code(pert,chi)
```

```
InvokeSchedule[invoke='invoke_propagate_perturbation',  
dm=False]
```

```
0: Extract[]
```

```
    Schedule[]
```

```
        0: Loop[type='', field_space='w3', it_space=...]
```

```
            Schedule[]
```

```
                0: CodedKern prop_pert_code(pert,chi)
```

Summary

- Defined Transformation and Transformation Script
- Showed how a transformation script can use transformations
- Looked at common PSyclone functions to use
- More about transformations in next sessions

Questions (1)

- Anything so far?



PSyData API

- An interface for an object-oriented Fortran library
- A set of transformations that insert calls to this library into a PSyclone application
- The Fortran library can either be:
 - A stand-alone application
 - Use an existing third party library



Example Application (1)

- Profiling
 - The PSyData transformations specify a profiling region
 - Typically call to third-party profiling library
 - E.g. DrHook, NVIDIA, dl_timer, ...
 - One simple stand-alone timer library
 - While profiling tools often provide their functions to define regions (and automatically instrument functions)
 - In some APIs a kernel computes one element
 - User can independent of tool specify region to measure

Example Application (2)

- Verify kernel parameter
 - Make sure no input parameter is NAN/infinite
 - Flag if a result of a kernel contains a NAN/infinite
 - Internally a dependency analysis determines input/output
 - Future: check if value is within a specified range
- Verify read-only parameters are not changed
 - Compiler only avoids explicit overwrites
 - This will not catch out-of-bounds array accesses (which are very expensive to test for)
 - Using checksum for fields

Example Application (3)

- Extract kernel parameter (PSyKE)
 - Write all input parameters to a file
 - Call kernel
 - Write all output parameters to the file
- Create driver that reads file and calls kernel
 - Maybe then compare results
- Useful for
 - Tuning science
 - Tuning performance
 - Creating unit tests

Planned Applications (4+5)

- In-situ visualisation
 - Plot fields while the application is running
- Compute diagnostic
 - CFL number of field



Intended Use for PSyData API

- It is mostly intended for tools
 - To help natural scientists and computer scientists to do their job
- Not as replacement for e.g. a proper IO library, or important diagnostics constantly used
 - If something is part of the application, it should not be added via PSyData

Some Details

- This slide is not actually required to use the transformations or any PSyData library
- But might give you an idea of what can be done with this interface
 - Develop your own tools
 - Suggest new tools to us
- Full details in PSyclone's developer's guide

The PSyData Calls

```
type(PSyData_type), save :: psy_data_var
call psy_data_var%PreStart("mod", "region", ...)
call psy_data_var%DeclareVariable("a", a)
call psy_data_var%DeclareVariable("b", b)
...
call psy_data_var%PreEndDeclaration()
call psy_data_var%ProvideVariable("a", a)
...
call psy_data_var%PreEnd()
! Execute kernel
call psy_data_var%PostStart()
call psy_data_var%ProvideVariable("b", b)
...
call psy_data_var%PostEnd()
```

The PSyData API

- Some functions are optional
 - If a transformation does not provide variables, no `Declare()` or `Provide()` functions will be used
 - E.g. profiling does only insert `PreStart()` and `PostEnd()` calls
- Many transformation will automatically select the variables
 - Based on variable usage analysis
 - Or they might take a list of parameters

Example Script (repeated ☺)

```
def trans(psy):
    from psyclone.psyir.transformations \
        import ExtractTrans
    extract = ExtractTrans()

    invoke    = psy.invokes.get("invoke_name")
    schedule = invoke.schedule
    schedule.view()
    # Enclose everything in an extract region
    options  = {}
    extract.apply(schedule, options)

    schedule.view()
    return psy
```

The PSyData Libraries

- Use Fortran generic interface
- Implemented using template language Ninja
 - Significantly reduces code duplication
- The PSyData libraries must be compiled and accessible when compiling the application
 - Needs the .mod files from the PSyData library
- Must be linked in with the application, before infrastructure libraries

Third Party Dependencies

- NAN-testing, read-only testing
 - No dependencies
- Kernel Extraction:
 - NetCDF
- Profiling
 - NVIDIA, DrHook, dl_timer, ...
 - Simple_timing stand-alone
- In all cases the safe link order is:
 - Application, PSyData, third-party, infrastructure

Classes of PSyData Applications

- The following PSyData classes are defined:
 - Profile, extract, read_only_verify, nan_test
- You can apply transformation from more than one class at the same time
 - Same file, even same region
- You cannot apply different transformations of the same class
 - Profiling with DrHook and NVIDIA at the same time

Existing PSyData Transformations

- **Profile:**

```
from psyclone.psyir.transformations
    import ProfileTrans
```

- **NAN:**

```
from psyclone.psyir.transformations
    import NanTestTrans
```

- **ReadOnly**

```
from psyclone.psyir.transformations
    import ReadOnlyVerifyTrans
```

- **Kernel Extraction**

```
from psyclone.psyir.transformations
    import ExtractTrans
```



Caveats

- Installation of PSyData libraries not done yet
 - You need to install git, and pre-compile the required libraries yourself
- We will design a better way of creating transformations
 - ATM you need to know if there is an API-specific implementation or a generic one
- Some transformations are work in progress
 - Driver that reads in kernel extraction not working yet



Summary

- Explained what PSyData is
 - Fortran object-oriented library
 - Set of transformations to insert calls into PSyclone code
- How to use the current PSyData tools

Hands-on

- Use the LFRic example from yesterday's session
 - Compileable and runnable version
- Apply kernel extraction to one kernel
- Apply kernel extraction to all kernels
- Apply NAN-checking and/or Read-only testing
- See directory
`tutorial/practicals/LFRic/building/4_psydata`



Australian Government
Bureau of Meteorology

Thank you

Joerg Henrichs, BOM
joerg.henrichs@bom.gov.au